




PROTECTED CONTACTOR

DC88P

The contactor can be mounted either horizontally or vertically. If mounted vertically the contact studs must point upwards.

All dimensions in millimetres